

## 463

**Stonethane  
(17% Solids)**

Date: \_\_\_\_\_

Batch Number: \_\_\_\_\_

Yield: **107 Gallons (405 Liters)**

Essential Batch Number: \_\_\_\_\_

1. Make sure blending tanks and equipment are clean.
2. Pump 52 gallons (197 liters) of water into mixing tank.
3. While agitating, slowly add 55 gallons (208 liters) of SUPERBASE 463 .
4. Continue agitating for (5) minutes. Batch complete.
5. Package in clean plastic drums and containers.
6. Product should stand for 24 hours before applying to floor.

*Note: One drum of 463 makes 107 gallons of 268.*

SDS and label copy for finished product may be obtained from Essential Industries at (800)-551-9679 or (262) 538-1122.