



Sports Floor Care

Sealing New or Newly Sanded Floors

© 2022 Essential Industries, Inc. L2922

1



The final sanding of the floor is done with a 120-grit screen.

2



Vacuum the floor thoroughly to remove all dust.

3



Thoroughly tack the floor twice with clean lint-free towels slightly moistened with Sport Tack (1129SF). Rotate and change towels often.

4



Inspect the floor. It should be dust-free. If dust is still present, re-tack the floor.

5



Apply two coats of Sport Seal (226SF). Allow it to dry for 12 hours under normal conditions - longer under humid conditions.

6



Lightly sand the floor with a Maroon SPP pad.

7



Vacuum floor thoroughly to remove all dust.

8



Thoroughly tack the floor twice with clean lint-free towels slightly moistened with Sport Tack (1129SF). Rotate and change towels often.

9



Mark game lines using recommended paints. Allow paint to dry for 24 hours. For game line details, refer to FIBA web site.

10



Lightly abrade game lines according to paint manufacturer's directions and then tack as indicated above.

11



Let floor dry completely before applying finish.

12



Apply three coats of Sport Kote[®] PC (128SF) – 2 coats the first day and 1 coat the next day. Consult label for complete finishing details, dry times and facility downtimes.